


User Manual

All in one system

GPSO-03K6L1-052A



*All in one system
(off-grid version)*

Contents

| | |
|--|-----------|
| ABOUT THIS MANUAL | 01 |
| Purpose | 01 |
| Scope | 01 |
| Safety instructions | 01 |
| WARNING MARKS | 02 |
| INTRODUCTION | 03 |
| Features | 03 |
| Basic system architecture | 03 |
| PRODUCT OVERVIEW | 04 |
| SPECIFICATIONS | 06 |
| INSTALLATION | 09 |
| Safety guidance | 09 |
| Unpacking and inspection | 09 |
| Installation location | 10 |
| AC input/output connection | 11 |
| PV connection | 13 |
| DC connection | 14 |
| Wiring System for Inverter | 15 |
| OPERATION | 16 |
| Power on/off | 16 |
| Operation and display panel | 16 |
| LCD display icons | 17 |
| LCD operation flow chart | 19 |
| Base information page | 19 |
| Setting page | 22 |
| Energy stored data page | 28 |
| BMS information page | 28 |
| Rated information page | 29 |
| Lithium battery communication | 30 |
| PARALLEL INSTALLATION GUIDE | 31 |
| Introduction | 31 |
| Mounting the unit | 31 |
| Package contents | 31 |
| Wiring connection | 31 |
| LCD setting and display | 36 |
| Commissioning | 36 |
| WARNING CODE TABLE | 37 |
| FAULT CODE TABLE | 37 |

ABOUT THIS MANUAL

Purpose

This manual describes the assembly, installation, operation, warning code and fault code of this unit. Please read this manual carefully before installations and operations. Keep this manual for future reference.

Scope

This manual provides safety and installation guidelines as well as information on tools and wiring.

Safety Instructions











WARNING: This chapter contains important safety and operating instructions. Read and keep this manual for future reference.

- Before using the unit, read all instructions and cautionary markings on the unit, the batteries and all appropriate sections of this manual.
- CAUTION** To reduce risk of injury, charge only deep-cycle lead acid type rechargeable batteries. Other types of batteries may burst, causing personal injury and damage.
- Do not disassemble the unit. Take it to a qualified service center when service or repair is required. Incorrect re-assembly may result in a risk of electric shock or fire.
- To reduce risk of electric shock, disconnect all wirings before attempting any maintenance or cleaning. Turning off the unit will not reduce this risk.
- CAUTION** Only qualified personnel can install this device with battery.
- NEVER** charge a frozen battery.
- For optimum operation of this inverter/charger, please follow required spec to select appropriate cable size. It's very important to correctly operate this inverter/charger.
- Be very cautious when working with metal tools on or around batteries. A potential risk exists to drop a tool to spark or short circuit batteries or other electrical parts and could cause an explosion.
- Please strictly follow installation procedure when you want to disconnect AC or DC terminals. Please refer to INSTALLATION section of this manual for the details.
- Fuse is provided as over-current protection for the battery supply.
- GROUNDING INSTRUCTIONS** This inverter/charger should be connected to a permanent grounded wiring system. Be sure to comply with local requirements and regulation to install this inverter.
- NEVER** cause AC output and DC input short circuited. Do NOT connect to the mains when DC input short circuits.
- WARNING!!** Only qualified service persons are able to service this device. If errors still persist after following troubleshooting table, please send this inverter/charger back to local dealer or service center for maintenance.
- WARNING!!** This series of off-grid inverters provides a backfeed function without grid-tie protection. If enabled, implement protective measures prior to operation. The customer assumes full liability for any accidents resulting from the use of this function.

WARNING MARKS

Warning marks inform users of conditions which can cause serious physical injury or death, or damage to the device. They also tell users how to prevent the dangers. The warning marks used in this operation manual are shown below:

| Mark | Name | Instruction | Abbreviation |
|---|-------------------------|--|---|
|  Danger | Danger | Serious physical injury or even death may occur if not follow relevant requirements. |  |
|  Warning | Warning | Physical injury or damage to the device may occur if not follow relevant requirements. |  |
|  Forbid | Electrostatic sensitive | Damage may occur if relevant requirements are not followed. |  |
|  Hot | High temperature | Do not touch the base of the inverter as it will become hot. |  |
| Note | Note | The procedures taken for ensuring proper operation. | Note |

INTRODUCTION

This is a multi-function inverter/charger, combining functions of inverter, MPPT solar charger and battery charger to offer uninterruptible power support with portable size. Its comprehensive LCD display offers user-configurable and easy-accessible button operation such as battery charging current, AC/solar charger priority, and acceptable input voltage based on different applications.

Features

- Pure sine wave inverter
- Built-in MPPT solar charge controller
- Configurable input voltage range for home appliances and personal computers via LCD setting
- Configurable battery charging current based on applications via LCD setting
- Configurable AC/Solar Charger priority via LCD setting
- Compatible to mains voltage or generator power
- Auto restart while AC is recovering
- Overload / Over temperature / short circuit protection
- Inverter running without battery
- Lithium battery activation function
- Cold start function
- The 3.6KW support 12 units in parallel.
- Intelligent fan control greatly reduces fan noise


Basic System Architecture

The following illustration shows basic application for this inverter/charger. It also includes following devices to have a complete running system:



- Generator or Utility
- PV modules (option)

Consult with your system integrator for other possible system architectures depending on your requirements.

This inverter can power all kinds of appliances in home or office environment, including motor-type appliances such as tube light, fan, refrigerator and air conditioner.




PRODUCT OVERVIEW



- | | |
|--------------------------------------|----------------------------------|
| 1. LCD display | 10. AC input(3P)/AC output(2P) |
| 2. Charging indicator | 11. AC input switch |
| 3. Fault or warning indicator | 12. PV input connection port |
| 4. Utility bypass/Inverter indicator | 13. Ground port |
| 5. ESC button | 14. DC circuit breaker |
| 6. UP button | 15. DC output (24V50A) |
| 7. Down button | 16. Switch |
| 8. Enter button | 17. Parallel connection-CAN port |
| 9. Three-prong outlet | 18. WIFI stick interface |

*Definition of BMS communication port pin



| NO. | BMS | RS-232 |
|-----|-----------|-----------|
| 1 | NC | RS232-TXD |
| 2 | NC | RS232-RXD |
| 3 | RS232-TXD | VDD |
| 4 | RS232-RXD | VSS |
| 5 | VSS | NC |
| 6 | VSS | NC |
| 7 | NC | NC |
| 8 | NC | VSS |

SPECIFICATIONS

| Line Mode Specifications | |
|--|--|
| Model | GPSO-03K6L1-052A |
| Rated Output Power | 3600VA |
| | 3600W |
| Nominal DC Input Voltage | 24V |
| Input Voltage Waveform | Sinusoidal (utility or generator) |
| Nominal Input Voltage | 230Vac |
| Low Line Voltage Disconnect | 90Vac±3V(For Home Appliances: APL)170Vac±3V(For Computers: UPS) |
| Low Loss Voltage Re-connect | 100Vac±3V(For Home Appliances: APL)180Vac±3V(For Computers: UPS) |
| High Line Voltage Disconnect | 280Vac±3V |
| High Line Voltage Re-connect | 270Vac±3V |
| Max AC Input Voltage | 280Vac±3V |
| Nominal Input Frequency | 50Hz/60Hz(Auto detection) |
| Low Line Frequency Disconnect | 40±1Hz |
| Low Line Frequency Re-connect | 42±1Hz |
| High Line Frequency Disconnect | 65±1Hz |
| High Line Frequency Re-connect | 63±1Hz |
| Output Voltage Waveform | As same as input waveform |
| Output Short Circuit Protection | Line mode: Circuit Breaker; Battery mode: Electronic Circuits |
| Efficiency (Line Mode) | >95%(Rated R load, battery full charged) |
| Transfer Time (Single unit) | 10ms typical (UPS); 20ms typical (Appliances) |
| Transfer Time (Parallel) | 50ms typical |
| Pass Through Without Battery | Yes |
| Max. Bypass Overload Current | 20A |
| Max. Bypass Input Current | 20A |
| Max. Inverter/Rectifier Current | 16.2A/3600W |

| Utility Charge Mode Specifications | | | |
|---|--|-----------------------|-------|
| Model | GPSO-03K6L1-052A | | |
| Nominal Input Voltage | 230Vac | | |
| Input Voltage Range | 90-280Vac | | |
| Nominal Output Voltage | Dependent on battery type | | |
| Max. Grid Charge Current | 125A | | |
| Charge Current Regulation | 1-125A-Max. Grid Charge Current (Adjustable unit is 1A) | | |
| Over Charge Protection | Yes | | |
| Grid charging Current (I.max/I.min) | 125A/30A | | |
| Relationship between battery charging current and grid voltage. | | | |
| Solar Charging & Grid Charging | | | |
| Max. PV Open Circuit Voltage | 500V | | |
| PV voltage range | 75V-425V | | |
| Max. Input Power | 4500W | | |
| Max. Solar Charging Current | 125A | | |
| Max. Charging Current(PV+Grid) | 125A | | |
| Max.PV Input Current | 18A | | |
| Min. Startup Voltage | 75V | | |
| Charge Algorithm | | | |
| Algorithm | Three stage: Boost CC (Constant current stage)-> Boost CV(Constant voltage stage)-> Float FV(Constant voltage stage) | | |
| Charging Curve | | | |
| Battery Type Setting | Battery Type | Boost CC/CV | Float |
| | AGM | 28.2V | 27V |
| | Flooded | 29.2V | 27V |
| | Self-defined | Adjustable, up to 30V | |
| | Lithium | Adjustable, up to 30V | |








| Inverter Mode Specifications | |
|---|---------------------------------|
| Model | GPSO-03K6L1-052A |
| Rated Output Power | 3600VA |
| | 3600W |
| Nominal DC Input Voltage | 24V |
| DC Max.charging/Discharging current | 125/170A |
| Output Voltage Waveform | Pure sine wave |
| Nominal Output Voltage | 230Vac±5% |
| Nominal Output Frequency(Hz) | 50±0.3Hz/60±0.3Hz(Adjustable) |
| Parallel capability | Yes, up to 12 units |
| Peak Efficiency | 93% |
| Over-Load Protection(SMPS load) | 2s@≥150%load; 10s@105%~150%load |
| Surge Rating | 2* rated power for 2s |
| Capable of Starting Electric | Yes |
| Output Short Circuit Protection | Yes |
| Cold Start Voltage | 23V |
| Low DC Input Shut-down Load < 50%/@Load ≥ 50% | 21.5V/21V |
| High DC Input Alarm & Fault | 31V±0.2V |
| High DC Input Recovery | 29V±0.2V |
| Battery Voltage Limitation (V.bat0/V.bat1/V.bat2) | 21V/24V/31V |
| When battery voltage is lower than "V.bat1", output power will be derated. The minimum AC output voltage is 180V. | |
| Temperature Limitation(Td) | 45°C |
| When ambient temperature is higher than 40°C/45°C, output power will be derated. The minimum Ac output voltage is 180V. | |
| General Specifications | |
| Operating Temperature | -10C° ~ 55C° |
| Range Storage Temperature | -15C° ~ 60C° |
| Net Weight(kg) | 59kg |
| Gross Weight(kg) | 66kg |
| Product Size(D*W*H) | 733x500x230mm |
| Package Dimension(D*W*H) | 820x590x390mm |

INSTALLATION

Safety Guidance










Warning marks inform users of conditions which can cause serious physical injury or death, or damage to the device. They also tell users how to prevent the dangers. The warning marks used in this operation manual are shown below:

WARNING!! Do not push or pull the machine from its front or back until it has been properly installed.

| | |
|--|---|
|  | <ul style="list-style-type: none"> • After receiving this product, first confirm the product package is intact. If any question, contact the logistic company or local distributor immediately. • The installation and operation of inverter must be carried out by professional technicians who have received professional trainings and thoroughly familiar with all the contents in this manual and the safety requirements of the electrical system. • Do not carry out connection/disconnection, unpacking inspection and unit replacement operations on the inverter when power source is applied. Before wiring and inspection, users must confirm the breakers on DC and AC side of inverter are disconnected and wait for at least 5 minutes. |
|  | <ul style="list-style-type: none"> • Ensure there is no strong electromagnetic interference caused by other electronic or electrical devices around the installation site. • Do not refit the inverter unless authorized. • All the electrical installation must conform to local and national electrical standards. |
|  | <ul style="list-style-type: none"> • Do not touch the housing of the inverter or the radiator to avoid scald as they may become hot during operation. |
|  | <ul style="list-style-type: none"> • Ground with proper technics before operation. |
|  | <ul style="list-style-type: none"> • Do not open the surface cover of the inverter unless authorized. The electronic components inside the inverter are electrostatic sensitive. Do take proper anti-electrostatic measures during authorized operation. |
|  | <ul style="list-style-type: none"> • The inverter needs to be reliably grounded. |
|  | <ul style="list-style-type: none"> • Ensure that DC and AC side circuit breakers have been disconnected and wait at least 5 minutes before wiring and checking. |

Unpacking and Inspection

Before installation, please inspect the unit. Be sure that nothing inside the package is damaged. You should have received the following items inside of package:


| | | | | |
|---|---|---|---|--|
|  <p>Inverter unit x 1</p> |  <p>Manual x 1</p> |  <p>mains terminal and output terminal x 1</p> |  <p>WiFi module x 1</p> |  <p>Self-tapping screw x 2 M4 x 2</p> |
|  <p>Case grounding screw x 1</p> |  <p>Locking wall bracket x 1</p> |  <p>Parallel communication cable and connector x 1</p> |  <p>Parallel communication connector x 1</p> | |

Installation location


Before selecting the installation location, please consider the following points:

- Do not install the solar inverter all-in-one machine on flammable building materials
- The ambient temperature should be between -10 °c and 55 °c to ensure optimal operation of the inverter.
- The installation posture is to place it on a horizontal ground to prevent tipping.
- Ensure that the distance between the surface of other objects placed and the inverter is as shown in the figure below, to ensure that the solar inverter integrated machine has sufficient space for heat dissipation and can remove wires.




 **SUITABLE FOR MOUNTING ON CONCRETE OR OTHER NON-COMBUSTIBLE SURFACE ONLY.**



- ◆ In order to ensure good heat dissipation and convenience in operation and maintenance, sufficient clearance shall be reserved while installing the battery. An example of such clearances are shown in the figure below. Please strictly follow the local battery installation guidelines, where applicable.



- ◆ Place the battery vertically in the installation.
- ◆ After placement, adjust the wheels to a fixed foot position for support, and all four wheels must be horizontal. Then rotate the fixing valve of the wheel to the right, and let the wheel be fixed in place.
- ◆ Installation is complete.



AC Input/Output Connection

CAUTION!! Before connecting to AC input power source, please install a separate AC breaker between inverter and AC input power source. This will ensure the inverter can be securely disconnected during maintenance and fully protected from over current of AC input. The recommended spec of AC breaker is 30A.

CAUTION!! There are two terminal blocks with "IN" and "OUT" markings. Please do NOT mis-connect input and output connectors.

WARNING! All wiring must be performed by qualified personnel.

WARNING! It's very important for system safety and efficient operation to use appropriate cable for AC input connection. To reduce risk of injury, please use the proper recommended cable size as below.

Suggested cable requirement for AC wires:


| Model | Gauge | Cable (mm ²) | Torque Value |
|-------|-------|--------------------------|--------------|
| 3.6KW | 10AWG | 6 | 1.2 Nm |

Recommended circuit breaker type for AC input:


| Models | Maximum bypass | Recommended circuit breaker |
|--------|----------------|-----------------------------|
| 3.6KW | 28A | 2P-30A |

Please follow below steps to implement AC input/output connection:


1. Before making AC input/output connection, be sure to open DC protector or disconnecter first.
2. Remove insulation sleeve 10mm for six conductors. And pressing ring terminal.



⊕ → Ground (yellow-green)
 L → LINE (brown or black)
 N → Neutral (blue)




3. Insert AC input wires according to polarities indicated on terminal block and tighten the terminal screws. Be sure to connect PE protective conductor (⊕) first.



WARNING:

Be sure that AC power source is disconnected before attempting to hardwire it to the unit. Each connection must be securely fastened. The exposed copper wires between the wires should not come into contact with each other; otherwise, there is a risk of fire.

4. Then, insert AC output/Generator input wires according to polarities indicated on terminal block and tighten terminal screws. Be sure to connect PE protective conductor (⊕) first.



5. Make sure the wires are securely connected.

CAUTION: Important

Be sure to connect AC wires with correct polarity. If L and N wires are connected reversely, it may cause utility short-circuited when these inverters are worked in parallel operation.

CAUTION: Appliances such as air conditioner are required at least 2~3 minutes to restart because it's required to have enough time to balance refrigerant gas inside of circuits. If a power shortage occurs and recovers in a short time, it will cause damage to your connected appliances. To prevent this kind of damage, please check manufacturer of air conditioner if it's equipped with time-delay function before installation. Otherwise, this inverter/charger will trig overload fault and cut off output to protect your appliance but sometimes it still causes internal damage to the air conditioner.

PV Connection

CAUTION: Before connecting to PV modules, please install separately a DC circuit breaker between inverter and PV modules.

WARNING! All wiring must be performed by qualified personnel.

WARNING! It's very important for system safety and efficient operation to use appropriate cable for PV module connection. To reduce risk of injury, please use the proper recommended cable size as below.

| Model | Cable Size | Cable (mm ²) | Torque |
|-------|------------|--------------------------|--------|
| 3.6KW | 10AWG | 6 | 1.2Nm |

PV Module Selection:

When selecting proper PV modules, please be sure to consider below parameters:

1. Open circuit Voltage (Voc) of PV modules not exceeds max. PV array open circuit voltage of inverter.
2. Max. power voltage (Vmp) should be during PV array MPPT voltage range.


| Solar Charging Mode | |
|------------------------------------|--------------|
| INVERTER MODEL | 3.6KW |
| Max. PV Array Open Circuit Voltage | 500V |
| PV Array MPPT Voltage Range | 85Vdc~450Vdc |

Please follow below steps to implement PV module connection:

1. Remove insulation sleeve 10mm for positive and negative conductors.



2. Check correct polarity of connection cable from PV modules and PV input connectors. Then, connect positive pole (+) of connection cable to positive pole (+) of PV input connector. Connect negative pole (-) of connection cable to negative pole (-) of PV input connector.



3. Make sure the wires are securely connected.

DC Connection


CAUTION: This port is a direct current output port. Please use it according to the specifications marked above (24V 50A). Otherwise, it will damage the machine or the electrical equipment!

WARNING! All wiring must be performed by qualified personnel.


WARNING! It's very important for system safety and efficient operation to use appropriate cable for connection. To reduce risk of injury, please use the proper recommended cable size as below.

WARNING! Please connect the device when the power is off or the circuit breaker is not closed. Do not plug or unplug it while the device is powered on.

| Model | Cable Size | Cable (mm ²) | Torque |
|-------|------------|--------------------------|--------|
| 3.6KW | 8AWG | 8 | 1.2Nm |




Wiring System for Inverter



— PV+ — PV- — L wire — N wire — PE wire — Binch power cord

OPERATION

Power ON/OFF



Press the button (when the button is in the pressed state), the all-in-one machine will be started. Wait for 10 seconds. Once the all-in-one machine is fully started, it will begin to output energy. Press the button again (when the button is not pressed), the power supply of the all-in-one machine will be cut off, and the output will stop. Wait for 10 seconds, and the screen of the all-in-one machine will go dark. Note: When the all-in-one machine is not in use, please turn off the power output!

Operation and Display Panel


The operation and display panel, shown in below chart, is on the front panel of the inverter. It includes three indicators, four function keys and a LCD display, indicating the operating status and input/output power information.



| Function Key | Icon | Description |
|--------------|------|---|
| ESC | ← | To previous page |
| UP | ↑ | To go to previous selection |
| DOWN | ↓ | To go to next selection |
| ENTER | ○ | To confirm the selection or go to next page |

| LED indicator | Icon | Description |
|--------------------|------|--|
| Battery | | Charging the battery, the LED light flash. If battery is full, the LED light will always-on. The battery is not charged, the LED light will go out. |
| Utility | | Inverter running in utility mode, the LED will always-on. |
| Inverter | | Inverter running in off-grid mode, the LED light will flash. Inverter is not running in off-grid mode, the LED light will go out. |
| Fault | | If inverter in fault event, the LED light will always-on. If inverter in warning event, the LED light will flash. Inverter work normally, the LED light will go out. |
| Buzzer Information | | |
| Buzzer beep | | Press any button, the buzzer will last for 0.1s. Hold on the "ENTER" button. the buzzer will last for 3s. If in fault event, the buzzer will keep going. If in warning event, the buzzer will beep discontinuous (Check more information on the chapter of "Warning Code Table"). |


LCD display Icons



| Icon | Function description |
|---|--|
| Input Source Information | |
| | Indicate input voltage, input frequency, PV voltage, PV power, battery voltage and charger current. |
| Configuration Program and Fault Information | |
| | Indicates the setting programs. |
| | Indicates the warning and fault codes. Warning: flashing with warning code. Fault: lighting with fault code. |

| Output Information | |
|----------------------------|--|
| | Indicate output voltage, output frequency, load percent, load in VA, load in Watt and discharging current. |
| Battery Information | |
| | Indicates battery level by 0-24%,25-49%,50-74% and 75-100%. The battery is connected normally, this icon is always on. |
| | If the inverter is in the process of lithium battery activation, or the battery is not connected, or the inverter is not connected to the grid and the battery voltage is low, this icon will flash. |
| | Indicates Lithium battery type. |
| | BMS Indicates communication is built between inverter and BMS. ▲ Indicates BMS allows battery discharge. ▼ Indicates BMS allows battery charge. Force charge occurs if icon flash. |
| Mode Operation Information | |
| | Indicates load is supplied by utility directly. |
| | Indicates the utility charger circuit is working. |
| | Indicates the inverter/charger is working. |
| | Indicates PV MPPT is working to power load. |
| | Indicates PV MPPT is working to charge battery. |
| | Indicates battery is discharging to load. |
| Mute Operation | |
| | Indicates unit alarm is disabled. |

LCD operation flow chart



On base information page, pressing and holding "ENTER" key for 3 sec, the unit will enter parameters page. Press "UP" or "DOWN" key to switch the selection and press "ENTER" key to enter selected page. Press "ESC" key to back to previous page.

Base information Page

1. The base information will be switched by pressing "UP" or "DOWN" key. The selectable information is switched as below order: (Take the 48V model for example).
2. The 2nd AC output is enabled in program 64, the "L1" or "L2" icon on the LCD will be showed, only show "L1" represent to main AC output data, only show "L2" represent to 2nd AC output data. show "L1" and "L2" represent to all AC output data("L1" + "L2").

| | |
|--|--|
| <p>Input voltage Output voltage Utility voltage is 230V, output voltage is 230V</p> | <p>Input frequency / Output voltage Utility frequency is 50.0Hz, output voltage is 230V</p> |
|--|--|

| | |
|--|---|
| <p>Generator voltage/Generator frequency Generator input voltage 230V, input frequency 50.0Hz</p> | <p>PV1 voltage / Output voltage PV1 voltage is 360V, output voltage is 230V</p> |
| <p>PV1 power / Output voltage PV1 power is 3.00kW, output voltage is 230V</p> | <p>PV2 voltage / Output voltage PV2 voltage is 360V, output voltage is 230V</p> |
| <p>PV2 power / Output voltage PV2 power is 3.00kW, output voltage is 230V</p> | <p>Battery voltage / Output voltage Battery voltage is 25.0V, output voltage is 230V</p> |
| <p>Charging current / Output voltage Charging current is 10A, output voltage is 230V</p> | <p>Battery voltage / Output frequency Battery voltage is 25.0V, output frequency is 50.0Hz</p> |
| <p>Battery voltage / Load percentage Battery voltage is 50.0V, load percentage is 40%</p> | <p>Battery voltage / L1 Load wattage Battery voltage is 25.0V, L1 output wattage is 6.16kW</p> |

| | |
|---|--|
| <p>Battery voltage / L2 Load wattage Battery voltage is 25.0V, L2 output wattage is 6.10kW</p> | <p>Battery voltage / Load VA Battery voltage is 25.0V, output wattage is 2.00kVA</p> |
| <p>Battery voltage / Load wattage Battery voltage is 25.0V, output wattage is 2.00kW</p> | <p>Battery voltage / Discharging current Battery voltage is 25.0V, discharging current is 80A</p> |
| <p>Battery voltage / SOC Battery voltage is 25.0V, SOC is 80%</p> | <p>Date 2023-06-01</p> |
| <p>Time 10:30:25</p> | |

Setting Page

Press "UP" or "DOWN" button to select setting programs. And then, press "ENTER" button to confirm the selection or ESC button to exit.

Keep pressing UP or DOWN button after 1.5 seconds, it will increase or decrease setting value quickly.

Setting items:

| | | Selectable option | | |
|----|--|-------------------|-------------------|--|
| 00 | Exit setting | | ESC | |
| 01 | Battery type setting | Default bAt | AGM | If "Self-defined" or "Lib" is selected, battery charge voltage and low DC cut-off voltage can be set up in program 03, 04 and 05. If "Lib" is selected, inverter can charge lithium battery when the lithium battery need to be activated. Please make sure lithium battery is connected before you start up inverter. If inverter doesn't connect battery or lithium battery, do not select "Lib" battery type. Note: The all-in-one machine must be set to the lithium battery mode. |
| | | bAt | FLD | |
| | | bAt | USE | |
| | | bAt | Lib | |
| 02 | BMS type | Default bns | 1 | Default Protocol. |
| | | BMS bns | 0 | Protocol 0. |
| 03 | Bulk charging voltage setting (CV voltage) | Default CV | 28.2 ^v | 24V model If "self-defined" or "Lib" is selected in program 01, this program is enabled. Setting range is from 24.0V to 30.0V. |
| 04 | Floating charging voltage | Default FLV | 27.0 ^v | 24V model If "self-defined" or "Lib" is selected in program 01, this program is enabled. Setting range is from 24.0V to 30.0V. |
| 05 | Low DC cut-off voltage or SOC | Default bcv | 21.0 ^v | 24V model If "self-defined" or "Lib" is selected in program 01, this program is enabled. Setting range is from 21.0V to 26.0V. |
| | | bcv | 10 % | If the battery type is lithium battery, the set value will change to SOC. Setting range is from 0% to 90%. |











| | | | | |
|----|--|------------------------------------|-------------------------------|--|
| 06 | Setting battery voltage or SOC point back to utility when selecting "SBU priority" in program 24 | Default 6U4 06 230 ^v | 24V model 230 ^v | Setting range is from 22.0V to 27.0V. Increment of each click is 0.1V. |
| | | Default 6U4 06 20% | 20% | If the battery type is lithium battery, the set value will change to SOC. Setting range is from 5% to 90%. |
| 07 | Setting battery voltage point back to battery mode when selecting "SBU priority" in program 24 | Default 66U 07 270 ^v | 24V model 270 ^v | Setting range is from 24.0V to 30.0V. Increment of each click is 0.1V. |
| | | 66U 07 FUL | Fully charged FUL | Battery should be charged to float charging stage. |
| | | Default 66U 07 70% | 70% | If the battery type is lithium battery, the set value will change to SOC. Setting range is from 10% to 100%. |
| 09 | Max charging current (Utility charge current +PV charging current) | Default 6CC 09 30 ^A | 30A 30 ^A | Setting range is from 1A to 125A. Increment of each click is 1A. |
| 10 | Max utility charging current setting | Default 6HC 10 30 ^A | 30A 30 ^A | Setting range is from 1A to 125A. Increment of each click is 1A. |
| 20 | AC output mode | Default PAL 20 510 | Single 510 | When the units are used in parallel with single phase, please select "PAL" in program 20. |
| | | PAL 20 PAR | Parallel PAR | |
| 21 | Output voltage setting | Default 0PU 21 230 ^v | 230V 230 ^v | Output voltage configuration. |
| | | 0PU 21 220 ^v | 220V 220 ^v | |
| | | 0PU 21 240 ^v | 240V 240 ^v | |
| 22 | Output frequency setting | Default 0PF 22 50 ^{Hz} | 50Hz 50 ^{Hz} | Output frequency configuration. |
| | | 0PF 22 60 ^{Hz} | 60Hz 60 ^{Hz} | |

NOTE: The setting value of item "07" should be larger than the setting value of item "06".

| | | | | |
|----|-----------------------------|--|---|---|
| 23 | Utility input range setting | Default AC 23 APL | Appliance mode APL | The APL mode is suitable for ordinary household electrical loads. UPS mode is suitable for computer loads. When the effect is not satisfactory, it is recommended to adjust to APL. |
| | | AC 23 UPS | UPS mode UPS | |
| 24 | Output source priority | Default 0PS 24 SUB | PV >> Utility >> Battery SUB | PV provides power to the loads first. If PV is not sufficient, utility will supply power the loads at the same time. Battery will provide power to loads only when utility is not available. |
| | | 0PS 24 USB | Utility >> PV >> Battery USB | Utility provides power to the loads first. PV and battery will provide power to loads only when utility is not available. |
| | | 0PS 24 SBU | PV >> Battery >> Utility SBU | PV provides power to the loads first. If PV is not sufficient, battery will supply power to the loads only when battery voltage drops to the setting point in program 6. |
| | | 0PS 24 INT | Intelligent output source priority INT | The intelligent priority can use more solar energy and save electricity bills. It is applicable to South Asia (such as Pakistan) and Africa. In this priority mode, the PV provides power to the loads first. If PV is not sufficient, battery or utility will supply power to the loads at the same time. If the energy storage system is not installed with solar panels, do not choose this priority mode. |
| 25 | Charger priority | If inverter is working in utility mode, charger priority can be set as below. However, when inverter is working in battery mode, only PV can charge battery. | | |
| | | Default CHS 25 SNU | PV and Utility SNU | PV and utility will charge battery together. |
| | | CHS 25 C50 | PV First C50 | PV will charge battery first. Utility will charge battery only when PV is unavailable. |
| | | CHS 25 O50 | PV Only O50 | Only PV can charge the battery. |
| 26 | Feeding power to grid | Disable FPG 26 DIS | Default DIS | If selected, inverter is not allowed to feed exceeding solar power to grid. |
| | | Enable FPG 26 ENA | ENA | If selected, inverter is allowed to feed exceeding solar power to grid. |









| | | | | |
|----|---|-------------------|----------------|---|
| 27 | Overload bypass function | Default LbP 27 | Enable ENa | If it is enabled, the inverter will switch to utility mode if overload happens in battery mode. |
| | | LbP 27 | Disable diS | |
| 28 | Overload restart function | Default OLr 28 | Enable ENa | If it is enabled, the inverter will auto restart when overload occurs. |
| | | OLr 28 | Disable diS | |
| 29 | Over temperature restart function | Default Otr 29 | Enable ENa | If it is enabled, the inverter will auto restart when over temperature occurs. |
| | | Otr 29 | Disable diS | |
| 31 | Zero Export Power | 2eP 31 | Default 0 | Regulate the input power of the Grid while in SBU Mode. Setting range is from -90W to 90W. Increment of each click is 5W. |
| 40 | Backlight of LCD | Default bL 40 | Disable diS | If selected, LCD backlight will be off after no button is pressed for 60s. |
| | | bL 40 | Enable ENa | If selected, LCD backlight will be always-on. |
| 41 | Auto return to the first page of display screen | Default bFP 41 | Enable ENa | If selected, it will automatically return to the first page of display screen (Default interface) after no button is pressed for 60s. |
| | | bFP 41 | Disable diS | If selected, the display screen will stay at latest screen user finally switches. |
| 42 | Buzzer alarm | Default bEP 42 | Enable ENa | If selected, buzzer is allowed to beep. |
| | | bEP 42 | Disable diS | If selected, buzzer is not allowed to beep. |
| 43 | Energy stored data for PV and load | Default ESd 43 | Disable diS | If selected, inverter will erase all historical data of PV and Load energy, and stop record historical data for PV and Load energy. |

| | | | | |
|----|---------------------|-------------------|----------------|---|
| | | ESd 43 | Enable ENa | If selected, inverter will record historical data for PV and Load energy. NOTE: Before selected, please double check if date and time is correct, if incorrect, please set date and time in program 50~55. |
| 44 | Reset default | Default rSt 44 | Disable diS | If selected, default initial settings page. |
| | | rSt 44 | Enable ENa | If selected, enabling the function will restore all settings except for the parallel settings and time settings. Output mode setting item (20) to their initial values. |
| 45 | Fan work mode | Default FAN 45 | PFC | In performance mode, the inverter will perform at it's highest performance. |
| | | FAN 45 | bLC | Balanced mode, applicable to the condition of 80% output power and 90A charge current limitation, to reduce additional noise greatly. |
| | | FAN 45 | sLC | Silent mode, applicable to the condition of 60% output power and 70A charge current limitation, to reduce additional noise extremely. |
| 46 | Failure recovery | Default FtS 46 | Disable diS | If selected, when the inverter enter the fault state, the inverter will not exit the fault state or start up again. |
| | | FtS 46 | Enable ENa | If selected, when the inverter enter the fault state, the inverter will exit the fault state and start up again. |
| 50 | Time setting-Year | Year YER 50 | 23 | Setting range is from 23 to 99. |
| 51 | Time setting-Month | Month nOn 51 | 8 | Setting range is from 1 to 12. |
| 52 | Time setting-Day | Day DAY 52 | 20 | Setting range is from 1 to 31. |
| 53 | Time setting-Hour | Hour HOu 53 | 21 | Setting range is from 0 to 23. |
| 54 | Time setting-Minute | Minute nIn 54 | 43 | Setting range is from 0 to 59. |

| | | | |
|----|---|--|---|
| 55 | Time setting-Second | Second SEC  50 | Setting range is from 0 to 59. |
| 60 | Low DC cut off voltage on second output | Default 24V model bcs  21.0V | Setting range is from 21.0V to 26.0V. Increment of each click is 0.1V. This low DC cut-off voltage will be fixed to setting value no matter what percentage of load is connected. |
| | | Default bcs  10% | If any type of lithium battery is selected in program 1, this parameter value will be displayed in percentage and value setting is based on battery capacity percentage. Setting range is from 0% to 95%. Increment of each click is 1%. |
| 62 | Scheduled time for 2nd AC output on | Default t d 0  0 | Setting range is from 00:00 to 23:00. Increment of each click is 1 hour. |
| 63 | Scheduled time for 2nd AC output off | Default t d F  0 | Within scheduled on/off time setting in program 62 and 63, 2nd AC output will be turn on/off. |
| 64 | Dual output Settings | Default Enable SPt  AUT | 1. The second output is normally on: The grid is power on. 2. The second output is turned off: The grid is power off and the battery voltage or SOC is less than program 60. 3. The second output is recovery: The grid is power off and the battery voltage > program 07 setting voltage, or the SOC > program 07 setting SOC. |
| | | SPt  t i n | 2nd AC output will be turn on/off according to setting in program 62 and 63. |
| | | SPt  d i s | Disabled, single output only. |
| 67 | Scheduled time for AC charge on | Default AC0  0 | Setting range is from 0~23 hour. If the time achieves the setting vaule, AC charge will be allowed/not allowed. |
| 68 | Scheduled time for AC charge off | Default ACF  0 | If the setting time for AC charge on and off are the same, the AC charge will be allowed always. |







Energy stored data Page


The energy stored data will be switched by pressing "UP" or "DOWN" key. The selectable information is switched as below order:

| | | |
|--|---|--|
| PV generated energy today 88 kWh  | PV generated energy this month 88 kWh  | PV generated energy this year 89 kWh  |
| PV generated energy current in total 348 kWh  | Load consumed energy today 78 kWh  | Load consumed energy this month 78 kWh  |
| Load consumed energy this year 80 kWh  | Load consumed energy in total 272 kWh  | |

BMS information Page





The BMS information will be switched by pressing "UP" or "DOWN" key. The selectable information is switched as below order: (Take the 48V model for example).

| | | |
|--|--|---|
| Battery pack number / mean SOC Connected battery pack number is 4, mean SOC is 97%  | BMS voltage / SOC BMS voltage is 54.0V, SOC is 99% on battery pack of address 1  | BMS voltage / current BMS voltage is 54.0V, current is 1A on battery pack of address 1  |
| Charge voltage limit /charge current limit Charge voltage is 58.4V, charge current is 100A on battery pack of address 1  | Discharge voltage limit /discharge current limit Discharge voltage is 43.4V, discharge current is 100A on battery pack of address 1  | BMS highest temperature /lowest temperature BMS highest temperature is 25°C, lowest temperature is 20°C on battery pack of address 1  |

| | | |
|---|--|--|
| <p>BMS fault code / flag BMS fault code is 0, flag is 000 on battery pack of address 1</p>  | | |
|---|--|--|

Rated information Page

The rated information will be switched by pressing "UP" or "DOWN" key. The selectable information is switched as below order:

| | | |
|---|---|---|
| <p>Rated VA / WATT Rated VA is 12kVA, WATT is 12kW</p>  | <p>Rated battery voltage / Max. charge current Rated battery voltage is 48V, Max. charge current is 210A</p>  | <p>Firmware version (Master DSP) Firmware version is 3102</p>  |
| <p>Firmware version (Slave DSP) Firmware version is 3001</p>  | | |


Lithium Battery Communication

1. It only allows the connection of lithium batteries and the establishment of configured communication. Please follow the steps below to configure communication between the lithium battery and inverter.
2. Configure the battery type to "Lib" in LCD settings project 01; Default "Lib" when leaving the factory.


The battery type is lithium battery




Then the LCD display will display the "Li" icon



3. Power the lithium battery and inverter, Wait a moment, if communication is established between them, the LCD will display the "BMS" icon, as shown below.



4. By pressing the "UP" or "DOWN" button to scroll through the real-time information on the LCD, as shown in the following figure, you can see the parameters of SOC in the communication system.



This page means SOC is 80%.

PARALLEL INSTALLATION GUIDE


Introduction

This inverter can be used in parallel with two different operation modes.
Parallel operation in single phase with up to 12 units for **3.6KW**, the supported maximum output power is 43.2kW/43.2kVA.

NOTE 1: If this unit is bundled with parallel cable, this inverter is default supported parallel operation.
You may skip section 2.

NOTE 2: Under parallel operation modes, battery must be connected with inverters.

Mounting the Unit



Note: To achieve proper air circulation for heat dissipation, please leave a gap of about 60 centimeters on the side and about 60 millimeters on the left and right sides of the device. Ensure that each unit is installed at the same level.

Package Contents

In parallel kit, you will find the following items in the package.




Parallel communication cable x 1 pcs




Parallel communication terminal connector x1 pcs

Wiring Connection

N Inverters Communication Connection




Parallel communication



Connect parallel communication cable one by one.

4*: Connect parallel communication connector to the first one and the last one.


Single Phase Parallel connection diagram for two inverters in parallel.




WARNING!! Strictly maintain insulation between PV ports in parallel systems. A single PV module's L/N lines **MUST NOT** be connected to PV ports of two or more inverters in the parallel configuration.

Note: Before starting up inverters, please connect all positive (+) and negative (-) wires of battery together.

Single Phase Parallel connection diagram for three to twelve inverters in parallel.





WARNING!! Strictly maintain insulation between PV ports in parallel systems. A single PV module's L/N lines **MUST NOT** be connected to PV ports of two or more inverters in the parallel configuration.



Note:

1. "n" is the number of parallel connections of the inverters.
2. Before starting up inverters, please connect all positive (+) and negative (-) wires of battery together.

LCD Setting and Display

Setting Program

| | | | |
|----|----------------|--------------------|---|
| 20 | AC output mode | Single 20 510 | When the units are used in parallel with single phase, please select "PAL" in program 20. |
| | | Parallel 20 PAL | |

Commissioning

Parallel in single phase


Step 1: Check the following requirements before commissioning:

- Correct wire connection.
- Ensure all breakers in Line wires of load side are open and each Neutral wires of each unit are connected together.

Step 2: Turn on each unit and set "PAL" in LCD setting program 20 of each unit. And then shut down all units.


NOTE: To be safe, it's better to turn off switch when setting LCD program.

Step 3: Turn on each unit.



Note: Master and slave units are randomly defined.


Step 4: Switch on all AC breakers of Line wires in AC input. It's better to have all inverters connect to utility at the same time. However, these inverters will automatically restart. If detecting AC connection, they will work normally.



Step 5: If there is no more fault alarm, the parallel system is completely installed.

Step 6: Please switch on all breakers of Line wires in load side. This system will start to provide power to the load.

WARNING CODE TABLE

When fault event happens, the fault LED is flashing. At the same time, warning code, icon  is shown on the LCD screen.

| Warning Code | Warning Information | Audible Alarm | Trouble shooting |
|--------------|--|-------------------------------|---|
| 01 | Overload | Beep twice every second | Reduce the loads. |
| 02 | Fan is locked (up) | Beep three times every second | Check if the Fans wiring connected well. Replace the fan. |
| 03 | Fan is locked (down) | Beep three time every second | Check if the Fans wiring connected well. Replace the fan. |
| 04 | Grid over voltage warning | No buzzer alarm | Check whether the grid voltage exceeds the allowable range of the inverter. |
| 05 | Output not connected together in parallel mode | No buzzer alarm | Check whether the output load of the inverter is normal, and check whether the inverters are connected together in the same phase. |
| 06 | Remote shutdown warning | No buzzer alarm | Check if remote shutdown is enabled via WIFI. Disable the enable or restart the inverter. |
| 07 | Second output overload | No buzzer alarm | Reduce the connected load by switching off some equipment, and restart the unit, if the error happens again, please return to repair center. |
| 08 | BMS communication failure | No buzzer alarm | Check whether the inverter 01 setting items selected for LI battery. If item 01 is set to lithium battery mode, check whether the communication line between the battery pack and the inverter is properly connected. |

FAULT CODE TABLE

When fault event happens, inverter will cut off output, and the fault LED is solid on. At the same time, fault code, icon **ERROR** is shown on the LCD screen.

| Fault Code | Fault information | Trouble Shooting |
|------------|--|--|
| 01 | Bus voltage is too high | AC Surge or internal components failed. Restart the unit, if the error happens again, please return to repair center. |
| 02 | Bus voltage is too low | Restart the unit, if the error happens again, please return to repair center. |
| 03 | Bus soft start fail | Internal components failed. Restart the unit, if the error happens again, please return to repair center. |
| 10 | Inverter soft start fail | Internal components failed. Restart the unit, if the error happens again, please return to repair center. |
| 11 | Over current or surge detected by Software | Restart the unit, if the error happens again, please return to repair center. |
| 12 | Over current or surge detected by hardware | Restart the unit, if the error happens again, please return to repair center. |

| | | |
|----|---|--|
| 13 | Output voltage is too low | Reduce the connected load. Restart the unit, if the error happens again, please return to repair center. |
| 14 | Output voltage is too high | Restart the unit, if the error happens again, please return to repair center. |
| 15 | Output short circuited | Check if wiring is connected well and remove abnormal load. |
| 16 | Inverter current sensor failed | Restart the unit, if the error happens again, please return to repair center. |
| 17 | Current feedback into the inverter is detected. | 1. Restart the inverter. 2. Check if L/N cables are not connected reversely in all inverters. 3. For parallel system in single phase, make sure the sharing cables are connected in all inverters. For supporting three-phase system, make sure the sharing cables are connected in the inverters in the same phase, and disconnected in the inverters in different phases. 4. If the problem remains, please contact your installer. |
| 20 | Overload time out | Reduce the connected load by switching off some equipment. |
| 21 | OP current sensor failed | Restart the unit, if the error happens again, please return to repair center. |
| 23 | The AC input and output wires are inversely connected | 1. Please check AC input and output wires are connected correctly. 2. If this error happens during parallel installation, please check wires connection. If they are connected correctly, please finish parallel installation first, and then restart inverters. 3. If the problem remains, please contact your installer. |
| 24 | The output relay exception | Restart the unit, if the error happens again, please return to repair center. |
| 30 | Battery voltage is too high | Check if spec and quantity of batteries are meet requirements. |
| 31 | Over current happen at DC/DC circuit | Restart the unit, if the error happens again, please return to repair center. |
| 34 | DC/DC soft start fail | Restart the unit, if the error happens again, please return to repair center. |
| 36 | Over current happen at LLC circuit | Restart the unit, if the error happens again, please return to repair center. |
| 37 | LLC hardware fault | Restart the unit, if the error happens again, please return to repair center. |
| 38 | BAT hardware fault | Restart the unit, if the error happens again, please return to repair center. |
| 40 | PV voltage is too high | Reduce the number of PV modules in series. |
| 41 | Short circuited happen at PV port | Check if wiring is connected well. |
| 42 | PV power abnormally | Restart the unit, if the error happens again, please return to repair center. |
| 43 | Over current happen at PV port | Restart the unit, if the error happens again, please return to repair center. |
| 50 | Fan is locked | Check if wiring is connected well. Replace the fan. |
| 51 | Over temperature happen at PV circuit | The temperature of internal PV component is over the limitation. Check whether the air flow of the unit is blocked or whether the ambient temperature is too high. |

| | | |
|----|---|---|
| 52 | Over temperature happen at INV circuit | The temperature of internal INV component is over the limitation. Check whether the air flow of the unit is blocked or whether the ambient temperature is too high. |
| 53 | Over temperature happen at Convert L circuit | The temperature of Convert L battery converter component is over the limitation. Check whether the air flow of the unit is blocked or whether the ambient temperature is too high. |
| 54 | Over temperature happen at Convert H circuit | The temperature of internal Convert H component is over the limitation. Check whether the air flow of the unit is blocked or whether the ambient temperature is too high. |
| 60 | CAN data loss | 1. Check if communication cables are connected well and restart the inverter. 2. If the problem remains, please contact your installer. |
| 61 | Host data loss | |
| 62 | Synchronization data loss | |
| 63 | The firmware version of each inverter is not the same | 1. Update all inverter firmware to the same version. 2. Check the version of each inverter via LCD setting and make sure the CPU versions are same. If not, please contact your installer to provide the firmware to update. 3. After updating, if the problem still remains, please contact your installer. |
| 64 | The output current of each inverter is different | 1. Check if sharing cables are connected well and restart the inverter. 2. If the problem remains, please contact your installer. |
| 65 | AC output mode setting is different | 1. Switch off the inverter and check LCD setting program 20. 2. For parallel system in single phase, make sure no 3P1, 3P2 or 3P3 is set on program 20. For supporting three-phase system, make sure no "PAL" is set on program 20. 3. If the problem remains, please contact your installer. |
| 66 | Single unit is installed to parallel system | 1. Please check if single unit is installed to parallel system. 2. If this error happens during parallel installation, please check wires connection. If they are connected correctly, please finish parallel installation first, and then restart inverters. 3. If the problem remains, please contact your installer. |
| 99 | Update fault | Restart the unit, if the error happens again, please return to repair center. |